



Carbide Filling Funnel

by Larry Click

This funnel makes filling carbide lamps easy. It drops in a measured amount with no fuss. The label on the side is an instruction sheet which I have reprinted below.

5 ¼" tall X 4 ¼" wide at top.

1 ¼" at bottom



DIRECTIONS for the use of FILLING FUNNEL

Drop into neck of lamp after Stopper Cup "D" is removed and pour carbide into the funnel until the carbide stops running; then hold funnel down with one hand and raise the wire ring in the middle of the funnel with the other hand and lift out of the lamp by the wire ring and set it in the carbide can and the carbide in the funnel will run back into the can. This ensures the filling of the lamp to the proper level each time.

When placing the funnel into the lamp see that the plug in the funnel is down so that the carbide will run into the lamp, and when removing the funnel from the lamp be sure that the wire ring is drawn up so it is closed. Always lift out of the lamp by the wire ring to avoid spilling carbide.

